## 



The aluminium extruded winding rolls are available in Ø45 or Ø60, in order to find a good solution for every room problem and are made with steel springs for the maximum toughness.

**ATTENTION: PRE-SET WRAPPING ROLL** 

## **D45**

In order to mount the roll, insert it into the proper supports, in the correct position, as indicated in the label on the roll itself.

The black band pointed out on the paper (right head-side of the roll) indicates the safety PIN position.

Fix the straps on the internal part of the last profile with rubber (only for ECO PLUS)

Place the roll with the safety pin (covered with a protection paper) so that it is positioned under the roll. Remove the protection paper, so that the safety pin will stick out of the roll.

Turn it manually in the loading direction and release it immediately. The loaded roll will wrap the straps and roll the shutter.

## **D60**

In order to mount the wrapping roll, place it into the proper supports in the correct position, like indicated (right side, seen from outside the vehicle)

The black band pointed out on the paper (right head-side of the roll) indicates the safety PIN position.

Place the roll with the safety pin (covered with a protection paper) so that it is positioned under the roll. Remove the protection paper, the safety pin will stick out of the roll.

## DON'T REMOVE THE SAFETY PIN UNTIL THE COM-PLETE ROLLER SHUTTER HAS BEEN MOUNTED.

In case the roll gets unloaded before the mounting has been completed, load it again following the loading direction and number of turns indicated on the roll, block it and insert the safety pin.

Repeat again all the previous points.

Don't load the roll in the wrong direction, as it will cause the irreparably damage of the roll (that has to be replaced).

